


Model No.DJV180 CORDLESS JIG SAW



Model No.DJV180 CORDLESS JIG SAW

Item No.	Parts No.	Description	Interchangability	Q'ty	New/Old	Note1	Note2
001	187725-4	Handle set		1			
001		INC. 25					
002	266048-4	Binding head tapping screw 4X40		1			
003	266091-3	Binding head tapping screw 4X50		1	*		
003-1	266467-4	Binding head tapping screw 4X50	O	1			
004	265995-6	Binding head tapping screw 4X18		5			
005	442138-9	Packing		1			
006	214031-5	Plane bearing 4		1			
007	232207-2	Leaf spring		1			
008	256117-9	Pin 4		1			
009	911111-5	Pan head screw M4X10 W		2			
010	911111-5	Pan head screw M4X10 W		2			
011	345240-6	Linear guide		1			
012	345240-6	Linear guide		1			
013	153338-3	Gear housing cover complete		1			
C10	253313-0	Thin washer 14		1			
C20	257250-0	Ring 20		1			
C30	421815-6	Dust seal 8		1			
014	631744-7	Light circuit		1			
015	689070-8	Heat sink		1	*		
015-1	689262-9	Heat sink	O	1			
016	911006-2	Pan head screw M3X8 W		1			
017	232152-1	Leaf spring		1			
018	419613-0	Lock off button		1			
019	650650-7	Switch C3LA-2A-PLSRS		1	*		
019-1	650650-7	Switch C3LA-2A-PLSRS	O	1			
020	233118-4	Compression spring 4		1			
021	419754-2	Switch lever		1			
022	324233-6	Safety wire		1			
023	266034-5	Binding head tapping screw 4X16		4			
024	644808-8	Terminal		1			
025	187725-4	Handle set		1			
025		INC. 1					
026	268090-1	Flat fillister HD. pin 4		1			
027	961017-7	Stop ring (EXT) E-3		1			
028	310134-4	Slider		1			
029	231659-4	Torsion spring 6		1			
030	419820-5	Tool opener		1			
031	265026-1	Pan head shoulder screw M4		1			
032	310135-2	Push pin		1			
033	421817-2	Dust cover		1			
034	962068-3	Retaining ring (INT) round R-18		1			
035	165326-8	Rod		1			
036	231660-9	Torsion spring 15		1			

037	310136-0	Blade holder		1		
038	188208-7	Motor housing set		1		
038		INC. 63				
039	265995-6	Binding head tapping screw 4X18		4		
040	815K50-6	Name plate DJV180		1		
041	638504-8	End bell complete		1		
042	638373-7	Yoke unit		1		
043	619206-5	Armature		1		
044	961004-6	Retaining ring (EXT) S-8		1		
045	212092-9	Needle bearing 407		1		
046	265353-6	Hex. socket head bolt M4X12		2	*	
046-1	265D42-7	Hex. socket head bolt M4X12	O	2		
047	153336-7	Crank complete		1		
048	313108-4	Balance plate		1		
049	158168-7	Gear complete		1		
050	345235-9	Push plate		1		
051	253877-4	Flat washer 8		1		
052	266050-7	Binding head tapping screw 4X30		4		
053	961018-5	Stop ring (EXT) E-5		1		
054	417839-8	Seal plate		1		
055	286032-3	Cap 5		1		
056	233139-6	Compression spring 3		1		
057	272280-0	Lever 17		1		
058	268063-4	Pin 4		1		
059	158169-5	Gear housing complete		1		
060	252171-1	Square nut M5-8		1		
061	421816-4	Dust seal		1		
062	153334-1	Retainer complete		1		
063	188208-7	Motor housing set		1		
063		INC. 38				
064	191971-3	Carbon brush set		1		
065	643807-7	Holder cap		2		
066	232208-0	Leaf spring		1		
067	922226-3	Hex. socket head bolt M5X18 W		1		
068	345237-5	Clamp plate		1		
069	317565-8	Base		1		
070	912107-9	Countersunk head screw M4X8		4		
071	345238-3	Base plate		1		
A01	415524-7	Kerf board		1		
A02	417852-6	Cover plate		1		
A03	417853-4	Dust nozzle		1		
A04	A-85737	JIGSAW BLADE NO.B22		1	*	
A04-1	A-85737	JIGSAW BLADE NO.B22	S	1		
A05	A-85628	JIGSAW BLADE NO.B10		1	*	
A05-1	A-85628	JIGSAW BLADE NO.B10	S	1		
A06	A-85793	JIGSAW BLADE NO.BR13		1	*	
A06-1	A-85793	JIGSAW BLADE NO.BR13	S	1		
A07	783202-0	Hex. wrench 4		1		
A08	***DC18RC	DC18RC FAST CHARGER		1		
A08	821550-0	Connector plastic case (type 2)		1		

C10	453974-8	Latch		4		
A09	194204-5	Battery BL1830 set		1	*	
A09	837639-4	Inner tray		1		
A09	196399-0	Battery BL1840 set		2	*	
A09-1	194204-5	Battery BL1830 set	O	1	*	
A09-1	196399-0	Battery BL1840 set	O	2	*	
A09-2	197600-6	Battery BL1830B set	<	1	*	
A09-2	197265-4	Battery BL1840B set	<	2	*	
A09-3	197600-6	Battery BL1830B set	O	1		
A09-3	197265-4	Battery BL1840B set	O	2		
A10	141486-0	Plastic case complete		1		
C10	450909-0	Latch		2		
A10L	803H12-8	Indication label DJV180ZJ		1		
A10	821550-0	Connector plastic case (type 2)		1		
C10	453974-8	Latch		4		
A10O	803X72-6	Indication label DJV180Y1J		1		
A11H	803H16-0	Model No. label DJV180RF		1		
A11I	803H17-8	Model No. label DJV180RFE		1		
A11J	803H19-4	Model No. label DJV180Z		1	*	
A11K	803H24-1	Model No. label DJV180RFE3		1		
A11L	803H13-6	Plastic case label DJV180ZJ		2		
A11	837639-4	Inner tray		1		
A11O	803X73-4	Plastic case label DJV180YJ		2		
A11Q	805D13-8	Model No. label DJV180RM		1		
A11-1J	816A37-1	Carton label DJV180Z	X	2	*	
A12	450128-8	Battery cover		1		
A12O	196235-0	Battery BL1815N set		1	*	
A12P	804V33-7	Indication label DJV180RM1J		1		
A12-1 O	196235-0	Battery BL1815N set	O	1		
A13M	803H10-2	Indication label DJV180RFJ		1		
A13N	803H14-4	Indication label DJV180RF1J		1		
A13P	804V34-5	Plastic case label DJV180RM1J		2		
A13R	804M33-3	Indication label DJV180RMJ		1		
A14M	803H11-0	Plastic case label DJV180RFJ		2		
A14N	803H15-2	Plastic case label DJV180RF1J		2		
A14R	804M34-1	Plastic case label DJV180RMJ		2		
A16	B-06292	JIGSAW BLADE ASSORT		2	*	
E01	688131-1	Line filter		1	*	
E01-1	688131-1	Line filter	O	1		
F01	192516-0	Guide rail set		1		
F02	192557-6	Kerf board set		1		
F03	194416-0	Sheet 10000 set		1		
F04	193516-3	Guide rule set		1		
C10	165217-3	Guide rule		1		
C20	271601-3	Knob 20		1		
C30	323802-0	Guide pin		1		
C40	922207-7	Hex. socket head bolt M5X10		1		
F05-1	193517-1	Guide rail adapter set	O	1		
C10	265785-7	Thumb screw M5X10		1		
C20	347393-7	Rule bar		1		
C30	417894-0	Guide rail adapter		1		

F07	194367-7	Guide rail 3000 set		1		
C10	413102-7	Seat 3000		2		
C20	423360-7	Position sheet 3000		1		
C30	423362-3	Rubber sheet 3000		2		
C40	819212-2	Makita logo label		1		
F08	194368-5	Guide rail 1400 set		1		
C10	413101-9	Seat 1400		2		
C20	423359-2	Position sheet 1400		1		
C30	423361-5	Rubber sheet 1400		2		
C40	819212-2	Makita logo label		1		
F09	194925-9	Guide rail 1900 set		1		
C10	423386-9	Position sheet 1900		1		
C20	423390-8	Rubber sheet 1900		2		
C30	451330-6	Sheet 1900		2		
C40	819212-2	Makita logo label		1		
F12-2	197252-3	Guide rail adapter set	O	1	*	
F12-3	197252-3	Guide rail adapter set	O	1		
F13	196448-3	Battery BL1815N set		1	*	
F13-2	196235-0	Battery BL1815N set	O	1		
F14-1	196449-1	Battery BL1815N set	O	1		
F15	196450-6	Battery BL1815N set		1	*	
F15-2	196449-1	Battery BL1815N set	O	1		
F17	199140-0	Guide rail 1000 set		1		
F18	199141-8	Guide rail 1500 set		1		
F19	194417-8	Rubber sheet 10000 set		1		
F20	194418-6	Position sheet 1400 set		1		
F21	194910-2	Position sheet 1900 set		1		

Please state Parts No. when your order.

Print Date 09/01/2025